


DIAMONDBACK *FITNESS*

1260ub Upright Bike

Owner's Manual





**Thank you for purchasing the
Diamondback Fitness 1260ub Recumbent Exercise Bike.
Please read through this owners manual carefully.**

**For the most up to date info about using your console and our
latest support videos, please visit www.diamondbackfitness.com**

**If you have any questions please contact our support team at
support@diamondbackfitness.com.**

Although current at the time of this printing, specifications for this model may have changed in our continuing effort for improvement. Diamondback Fitness reserves the right to modify and improve the specifications of its products without prior notice.

Safety Instructions & Warnings

Every piece of Diamondback Fitness equipment is built for maximum safety and meets or exceeds all applicable domestic and international standards. However, certain precautions must be taken when operating any piece of fitness equipment.

NOTE: Please read the entire owner's manual before operating the unit. Save this manual for future reference.

Cautions – For Safe Operation

- Keep hands and feet away from all moving parts and pinch points.
- If you have a history of heart disease, high blood pressure, diabetes, chronic respiratory diseases, elevated cholesterol, or if you smoke cigarettes or experience any other chronic diseases or physical complaints, consult with a physician before beginning any exercise program.
- If overweight or above the age of 35, consult with your physician before beginning an exercise program.
- Pregnant women should consult with their physician before beginning an exercise program.
- If you experience dizziness, nausea, chest pains or other abnormal symptoms during exercise, stop the exercise session immediately and consult your physician.
- Consume water before, during and after each exercise session.

Warnings – To Reduce the Risk of Injury to Yourself and Others


- To ensure proper functioning of your unit, do not install attachments or accessories not provided or recommended by Diamondback Fitness.
- Always wear proper clothing and shoes when exercising.
- User weight is not to exceed 300 pounds (136 Kg) for this unit.
- Keep children away from the unit. Hands and feet may become entangled with the moving parts and could result in serious injury.

- Place the unit in an area that will meet minimum clearance requirements:
front & sides = 24 inches (61 cm)
rear = 12 inches (30.5 cm)
- The unit is intended for indoor use only.
- Place the unit on a solid, level surface. Always adjust the leveling feet before using to ensure stability.
- Ensure all adjustment knobs and levers are fastened securely before using the unit and after making an adjustment.
- Use the handlebars when stepping on and off the unit.
- The unit is heavy. Do not attempt to move alone.
- Never operate the unit if it is damaged or broken.
- Please unplug the unit after exercising.
- Always unplug the unit from the power source before moving or servicing.


Unpack Your Box

Unpack the box making sure all the parts are accounted for.


1: MAIN FRAME




2: REAR STABILIZER




4: FRONT STABILIZER




5: COVER - STABILIZERS




13: SEAT POST




17: FRONT POST




36: HANDLEBAR



76: CONSOLE




TOOLS AND HARDWARE




42: COVER - HANDLEBAR



40: COVER - CONSOLE BACK




51: PEDALS




51L: LEFT 51R: RIGHT

69: SADDLE



75: UPPER COVER




66: POWER CABLE



Please don't use power tools for any part of the assembly.

Attach the Front Stabilizer

Tools



Parts:



- | | |
|-----------------------------|-------------------------------|
| 1 : Main Frame | 7A : M8x1.25x110L Bolt |
| 4 : Front Stabilizer | 9 : Spring Washer |
| 7 : M8x1.25x70L Bolt | 16 : Flat Washer |

1

Throw away the fixing tube including two bolts into the trash. They are not needed for assembly.


2

Take the packing material styrofoam and put it under the rear frame to assemble the front stabilizer (**4**) onto the main frame (**1**) using the cross bolt (**7&7A**), the spring washer (**9**) and the flat washer (**16**).



Attach the Rear Stabilizer

Tools



Parts:

1 : Main Frame

2 : Rear Stabilizer

7 : M8x1.25x70L Bolt

7A : M8x1.25x110L Bolt

9 : Spring Washer



16 : Flat Washer

1

Throw away the fixing tube and bolts into trash.
They are not needed for assembly.


2

Take the packing styrofoam and put it under the rear frame to assemble the rear stabilizer (**2**) onto the main frame (**1**), using the cross bolt (**7&7A**), the spring washer (**9**) and the flat washer (**16**).



Assemble the Seat Post

Tools



Parts:

13 : Seat Post




69 : Saddle

1

Attach the seat (**69**) onto the seat post by tightening the two hex nuts located on the bottom of the seat.


2

Then slide the seat post (**13**) into the main frame of the bike as shown.



Attach the Front Post

Tools




Parts:

17 : Front Post
75 : Upper Cover

15 : M8x1.25x15L
9 : Spring Washer
16 : Flat Washer



1

Slide the upper plastic cover (**75**) onto the front post (**17**) then connect the lower and upper console cable (**64 & 65**).




2

Attach the front post (**17**) onto the main frame using the flat washer (**16**), the spring washer (**9**), and bolt (**15**). Slide down the upper cover (**75**) and make sure it is flush with the front post.



Attach the Console

Tools



Parts:

40 : Console Back

39 : M5x0.8x12L


76 : Console

1

Connect the console (76) with upper console cable (64).

76

64




2

Thread the console cable into the front post (17) and then out of the handlebar mount hole like shown.

17

76




3

Attach the console (76) onto front post (17) using the fixing bolts (39).

76

39

17





4

Attach the back console cover (40) to the console using the fixing bolts (39).

40


39

17



Attach the Handlebars

Tools



Parts:

36 : Handlebar
42 : Handlebar Cover


39 : M5x0.8x12L
41 : M8x1.25x50L
8 : Curve Washer

1

Connect the console (**76**) with the left quick button cable (**37L**) and right quick button cable (**37R**).


2

Attach the handlebar (**36**) onto the front post (**17**) using the curve washer (**8**) and bolt (**41**). Then snap the the handlebar cover (**42**) into place over the bolts (**41**).



Attach Pedals and Covers

Tools



Parts:

51R: Right Pedal

51L: Left Pedal

5 : Stabilizer Covers

39 : M5x12L

1

Attach the front and rear stabilizer covers (**5**) using the cross bolts (**39**).


2

Attach the pedals. Start with the rider's right pedal (**51R**). Begin by finger tightening the pedal onto the crank arm. **Turn the right pedal CLOCKWISE.**

Be sure not to cross thread the pedal. This could damage the pedal and crank arm.

Repeat for the left pedal (**51L**). However, **turn the left pedal in COUNTER-CLOCKWISE** direction.

After finger tightening as far as possible, finish with the tool provided, making sure both pedals are fully seated and tight against the crank arm.




Powering the 1260ub and Final Adjustments


For the most up to date info about using your console and our latest support videos, please visit www.diamondbackfitness.com

Plug one end of the power adapter **(66)** into the outlet and the other end into the unit input power jack located in the front plastic housing.


66



Using the seat post lever, you can adjust the seat position vertically. Using the seat slide lever, you can adjust the seat position horizontally.



Level the unit by rotating the four leveling feet located in the bottom of the front and rear stabilizer bars.



Troubleshooting

Please do the following hard reset if you notice any small glitches in the console or resistance.

1. Make sure the unit is unplugged from the power source.
2. Remove the four screws holding the console cover to the unit and then remove the four screws holding the console to the console mast.
3. Unplug the upper console cable **(64)** from the back of the console for a period of five minutes.
4. Reconnect cable and plug the power source back in to test.

Maintenance

All Diamondback Fitness products are engineered for years of near-silent operation. Let noise be your first indication that a repair or adjustment is required. Please, discontinue use immediately and contact customer support or Diamondback Fitness Dealer if an unusual noise, scraping, knocking, grinding or vibration is detected. Often, a minor issue will become a major repair if ignored and use is continued.

Prior to each workout, confirm that all adjustment levers and screws are tightened.

Tighten the crank arms once per month. Loose crank arms will become damaged and are not covered under the warranty.

Your Diamondback Fitness product is manufactured of the most durable materials available. The plastics are molded of strong and chemical-resistant ABS and PVC. The frame is produced of high-tensile steel and protected with an industrial-grade, powder paint coating for the highest level of corrosion resistance. It is important to note however, that perspiration can be extremely corrosive if allowed to accumulate on the machine. After training, always wipe

Maintenance Cont'd

down the unit with a mild soap solution followed by a thorough drying with a clean towel. Positioning a small spray bottle and towel near the unit will help ensure that your Diamondback Fitness equipment looks new for many years.

Note: Perspiration is very corrosive and if allowed to remain on the machine, will cause discoloration, fading, rust and odors. Unfortunately, these conditions are not covered under the Warranty Policy.

Warranty Information

Diamondback Fitness warrants this unit to be free from defects in material and workmanship under normal use in the home environment. Diamondback Fitness's obligation under this warranty is limited to the repair or replacement of any defective part, provided free of charge. This warranty is extended to the original purchaser. The following conditions apply:

Who is Covered

The warranty is extended to the individual whose name appears on the original sales receipt and may not be transferred to any other individual or legal entity.

To Obtain Service

To obtain service under warranty, you must contact Diamondback Fitness customer support at support@diamondbackfitness.com

Proof of Purchase

Proof of purchase from a Diamondback Fitness Authorized Dealer or Diamondbackfitness.com will be required.

What is Covered – For Interior Residential Use Only.

Note: If proof of purchase cannot be confirmed, the Warranty's coverage period will begin on the date six (6) months after the date of manufacture.

Warranty Information Cont'd

Note: Limited lifetime refers to warranty coverage of the unit's expected service life, not the lifetime of the purchaser. The expected lifetime of this unit is five (5) years from the date of purchase although other factors can extend this period. Support and maintenance of the unit may become difficult or impossible after this period expires.

Frame :	Limited lifetime warranty; covers defects in welds, materials and workmanship (some exclusions apply).
Brake :	3 years
Parts & Electronics :	3 years
Labor :	1 year

Voided Warranty

The warranty does not apply to any failure of the product or its components due to alterations or modifications, misuse and abuse, accidental damage, lack of maintenance or improper assembly. Improper assembly can be avoided if the unit is assembled by an authorized technician. Damage due to improper assembly is not covered by the warranty. Common assembly errors can include damaged wire harnesses, stripped screws and nuts, crank arms or damaged threads.

If the serial number has been removed, altered or defaced, the warranty for the affected unit is voided.

Parts & Service

Contact the Diamondback Fitness support or the dealer that originally sold the unit. If you have moved, or the retailer is unavailable, contact us at support@diamondbackfitness.com to help locate an alternate Authorized Dealer.

Diamondback Fitness is not responsible for securing warranty service and/or honoring extended warranties provided by dealers.

NOTE: Authorized service technicians do not reside in all areas of the country. If you live beyond the reasonable service area of a metropolitan area, Diamondback Fitness may not be able to support the labor portion of the product warranty. Travel fees charged by technicians are not covered by the warranty.

Other Exclusions


The warranty for this unit is void if it is placed in commercial or light commercial environments such as health clubs, schools, hotels, condominium common areas, correctional facilities, or any other non-residential setting. The warranty will not be honored if this unit is employed for commercial or rental purposes. This unit is for indoor use only.

Additional Rights

This Warranty is expressly in lieu of all other warranties, and any implied warranties of merchantability or fitness for a particular purpose created hereby, and are limited to the same duration as the express warranty herein. Diamondback Fitness shall not be liable for any incidental or consequential damages. Some states do not allow the exclusion or limitations of implied warranties, incidental or consequential, so the above limitations and exclusions may not apply to you.

Retailers and wholesale outlets for Diamondback Fitness products are not authorized to modify this warranty in any way.

This warranty gives the original owner specific legal rights. Other additional rights may vary from state to state.



For the most up to date info about using your console and our latest support videos, please visit www.diamondbackfitness.com

If you have any questions please contact our support team at support@diamondbackfitness.com.

DIAMONDBACKFITNESS